



MAG-STOW PACKING INSTRUCTIONS

1. STOW YOUR LINES WITH THE 2 RUBBER BANDS TO HOLD THE BAG CLOSED.



2. ROTATE THE BAG SO THAT THE LINE STOW POUCH IS FACING UP, AND FOLD THE MAGNETS DOWN TO OPEN THE POUCH.



3. ROUTE THE LINES STRAIGHT DOWN THE CENTER OF THE POUCH BETWEEN THE MAGNETS AND THEN S-FOLD THE LINES BACK AND FORTH.



4. INSERT THE MAGNETIC TABS INTO THE POCKETS AND ROTATE THE BAG BACK TO THE ORIGINAL POSITION.



5. PLACE THE BAG IN CONTAINER IN THE NORMAL MANNER.

